

PEUGEOT - CITROEN - OPEL - DS

YEDKA®
OTOMOTIV A.Ş.

YDK100



OEM CODE: 5038.G6-5031.F2
PEUGEOT: 2008-207-208-301
CITROEN: C ELYSEE-C3-C4 CACTUS-DS3

SHOCK ABSORBER MOUNTING

YDK100-R



OEM CODE: 5038.G6-5031.F2
PEUGEOT: 2008-207-208-301
CITROEN: C ELYSEE-C3-C4 CACTUS-DS3

SHOCK ABSORBER MOUNTING WITH BEARING

YDK101



OEM CODE: 5038.85-5038.46-5038.G0
PEUGEOT: 307-308-3008-PARTNER
CITROEN: C4-BERLINGO

SHOCK ABSORBER MOUNTING

YDK101-R



OEM CODE: 5038.85-5038.46-5038.G0
PEUGEOT: 307-308-3008-PARTNER
CITROEN: C4-BERLINGO

SHOCK ABSORBER MOUNTING WITH BEARING

YDK102



OEM CODE: 5038.F5-5038.A9
PEUGEOT: 1007
CITROEN: C2-C3

SHOCK ABSORBER MOUNTING

YDK102-R



OEM CODE: 5038.F5-5038.A9
PEUGEOT: 1007
CITROEN: C2-C3

SHOCK ABSORBER MOUNTING WITH BEARING

YDK103



OEM CODE: 1806.59-95516322-9645688080
PEUGEOT: 1007-206-207-208-301-2008
CITROEN: C ELYSEE-C2-C3-DS-DS3

ENGINE MOUNTING REAR

YDK104



OEM CODE: 5033.75-5033.69-5033.C9
PEUGEOT: 1007-2008-3008-207-208-301-307-308-508-PARTNER-RCZ
CITROEN: BERLINGO-C ELYSEE-C2-C3-C4-DS3-DS4
DS: DS 3

SHOCK ABSORBER PLATE

YDK105



OEM CODE: 5035.27-546122C000-9151063380
PEUGEOT: 1007-2008-3008-5008-106-205-206-207-208-301-305-306-307-308-309-405-PARTNER-RCZ
CITROEN: AX-BERLINGO-SAXO-XSARA-VISA-ZX-C ELYSEE-C2-C3-C4-C15-DS3-DS4-DS5
DS: DS 3-DS 4

SHOCK ABSORBER BEARING

YDK106



OEM CODE: 1806.59-9645688080
PEUGEOT: 1007-2008-206-207-208-301
CITROEN: C ELYSEE-C2-C3-DS-DS3

ENGINE MOUNTING REAR

YDK107



OEM CODE: 1806.A6-1806.J8-1806.93
PEUGEOT: 207-208-301-308 I-2008 I-3008 I
CITROEN: C ELYSEE-C3-C4 II-DS3-DS4
DS: DS 3

ENGINE MOUNTING REAR

YDK108



OEM CODE: 5038.91-5031.80-9646254781
CITROEN: C2-C3

SHOCK ABSORBER MOUNTING

PEUGEOT - CITROEN - OPEL - DS

YEDKA®
OTOMOTIV A.Ş.

YDK108-R



OEM CODE: 5038.91-5031.80-9646254781
CITROEN: C2-C3

SHOCK ABSORBER MOUNTING WITH BEARING

YDK300 RH/LH



OEM CODE: 51804747-51839975
PEUGEOT: BIPPER
CITROEN: NEMO
OPEL: COMBO

SHOCK ABSORBER MOUNTING RIGHT/LEFT

YDK300-R RH/LH



OEM CODE: 5038.G2-51890881-5038.G3
PEUGEOT: BIPPER
CITROEN: NEMO
OPEL: COMBO

SHOCK ABSORBER MOUNTING RIGHT/LEFT

YDK304



OEM CODE: 51804747-51839975-1609274780
PEUGEOT: BIPPER
CITROEN: NEMO
OPEL: COMBO

SHOCK ABSORBER BEARING

RENAULT - DACIA

YDK309



OEM CODE: 1844.C7-51813604-51805435
PEUGEOT: BIPPER
CITROEN: NEMO

ENGINE MOUNTING REAR

YDK200



OEM CODE: 8200103263-8200272424
RENAULT: MEGANE-SCENIC-GRAND SCENIC

ENGINE MOUNTING REAR

YDK201



OEM CODE: 8200222463
RENAULT: CLIO-MEGANE-SCENIC-
GRAND SCENIC

SHOCK ABSORBER MOUNTING

YDK202



OEM CODE: 8200053795-5433000QAA
RENAULT: CLIO-KANGOO-GRAND KANGOO-
MEGANE-SYMBOL-TWINGO-THALIA

SHOCK ABSORBER MOUNTING

RENAULT - DACIA

YEDKA®
OTOMOTIV A.Ş.

YDK202-R



OEM CODE: 8200053795-5433000QAA
RENAULT: CLIO-KANGOO-GRAND KANGOO-
MEGANE-SYMBOL-TWINGO-THALIA

SHOCK ABSORBER MOUNTING WITH BEARING

YDK203



OEM CODE: 6001547499-8200275528
RENAULT: CLIO-DUSTER-KANGOO-LOGAN-
SANDERO/STEPWAY-TWINGO-THALIA
DACIA: DOKKER-DOSTER-LODGY-
LOGAN-SANDERO

SHOCK ABSORBER MOUNTING

YDK203-R



OEM CODE: 6001547499-8200275528
RENAULT: CLIO-DUSTER-KANGOO-LOGAN-
SANDERO/STEPWAY-TWINGO-THALIA
DACIA: DOKKER-DOSTER-LODGY-
LOGAN-SANDERO

SHOCK ABSORBER MOUNTING

YDK204



OEM CODE: 112381035R-112383905R
RENAULT: CAPTUR-CLIO
DACIA: DOKKER-LODGY-LOGAN-SANDERO

ENGINE MOUNTING REAR

RENAULT - DACIA

YDK205



OEM CODE: 543200001R-540340002R
RENAULT: FLUENCE-MEGANE-SCENIC-LAGUNA

SHOCK ABSORBER MOUNTING

YDK206



OEM CODE: 6001549205-8200575641-11360BV000
RENAULT: CLIO-LOGAN-MEGANE-MODUS-
SANDERO/STEWAY-SCENIC-
GRAND SCENIC-THALIA

ENGINE MOUNTING REAR

YDK207



OEM CODE: 543206968R-543207020R
RENAULT: ESPACE-ESPACE V-GRAND SCENIC-
GRAND SCENIC IV-KADJAR-KOLEOS II-MEGANE IV-
SCENIC IV-TALISMAN

SHOCK ABSORBER MOUNTING

YDK208



OEM CODE: 543024644R
RENAULT: CAPTUR-CLIO-MODUS-GRAND MODUS-
THALIA-TWINGO-ZOE

SHOCK ABSORBER MOUNTING

RENAULT - DACIA

YDK209



OEM CODE: 7700800107-8200651172-5432500QAA
RENAULT: CLIO-DUSTER-KANGOO-GRAND KANGOO-
LOGAN-MEGANE-SANDERO/STEPWAY-SCENIC-
SYMBOL-THALIA-TWINGO-WIND
DACIA: DOKKER-DUSTER-LODGY-LOGAN-SANDERO

SHOCK ABSORBER BEARING

YDK210



OEM CODE: 6001548402-8200437347-540505149R
RENAULT: CLIO-DUSTER-LOGAN-
SANDERO/STEWAY-SYMBOL-THALIA
DACIA: DUSTER-LOGAN-SANDERO

SHOCK ABSORBER DUST BELLOW

YDK211



OEM CODE: 7701464321
RENAULT: R9-R11-R19

TORSION REPAIR KIT

YDK213



OEM CODE: 8200275524-8200742906-54467AX600
RENAULT: CLIO-MEGANE-MODUS-GRAND MODUS-
SCENIC-GRAND SCENIC

ENGINE CRADLE BUSH

FIAT-LANCIA-ABARTH

YEDKA®
OTOMOTIV A.Ş.

YDK300 RH/LH



OEM CODE: 51804747-51839975
FIAT: DOBLO-FIORINO-LINEA-PUNTO-GRANDE PUNTO-QUBA
ABARTH: PUNTO-GRANDE PUNTO

SHOCK ABSORBER MOUNTING RIGHT/LEFT

YDK300-R RH/LH



OEM CODE: 5038.G2-51890881-5038.G3
FIAT: DOBLO-FIORINO-LINEA-PUNTO-GRANDE PUNTO-QUBA
ABARTH: PUNTO-GRANDE PUNTO

SHOCK ABSORBER MOUNTING WITH BEARING

YDK301



OEM CODE: 50702841-50700886
FIAT: BRAVO-STILO
LANCIA: DELTA

SHOCK ABSORBER MOUNTING

YDK302 RH/LH



OEM CODE: 46760673-46760674
FIAT: ALBEA-DOBLO-PALIO-SIENA-STRADA-UNO

SHOCK ABSORBER MOUNTING RIGHT/LEFT

FIAT-LANCIA-ABARTH

YDK304



OEM CODE: 51804747-51839975-1609274780
FIAT: DOBLO-FIORINO-LINEA-PUNTO-GRANDE PUNTO-QUBA
ABARTH: PUNTO-GRANDE PUNTO

SHOCK ABSORBER BEARING

YDK305



OEM CODE: 46466619
FIAT: ALBEA-DOBLO-PALIO-SIENA-STRADA

SHOCK ABSORBER DUST BELLOW

YDK309



OEM CODE: 1804.C7-51813604-51805435
FIAT: DOBLO-FIORINO-LINEA-QUBO

ENGINE MOUNTING REAR

YDK311



OEM CODE: 52120559-52031639-51983626
FIAT: EGEA-TIPO

SHOCK ABSORBER MOUNTING FRONT

YDK311-R



OEM CODE: 52120559-52031639-51983626
FIAT: EGEA-TIPO

SHOCK ABSORBER MOUNTING WITH BEARING

YDK400



OEM CODE: 30616824-30889584
VOLVO: S40-V40

SHOCK ABSORBER MOUNTING

YDK401



OEM CODE: 1230960-1305954-CV613K155B2B
VOLVO: C30-C70-S40-V50

SHOCK ABSORBER MOUNTING

YDK401-R



OEM CODE: 1230960-1305954-CV613K155B2B
VOLVO: C30-C70-S40-V50

SHOCK ABSORBER MOUNTING WITH BEARING

YDK402



OEM CODE: 150811-30639948-3M513K099AD
VOLVO: C30-C70-S40-V40-V50

SHOCK ABSORBER BEARING

YDK403



OEM CODE: 9461728-30683637-8646713
VOLVO: 850-C70-S60-S70-S80-S90-
XC70-XC90-V70

SHOCK ABSORBER MOUNTING

YDK505



OEM CODE: 1061668-1231455-98AG5K743AF
VOLVO: C30-C70-S40 II-S70-V50-V70

BALANCE ARM REAR

YDK401



OEM CODE: 1230960-1305954-CV613K155B2B
FORD: CMAX-FOCUS-KUGA

SHOCK ABSORBER MOUNTING

YDK401-R



OEM CODE: 1230960-1305954-CV613K155B2B
FORD: CMAX-FOCUS-KUGA

SHOCK ABSORBER MOUNTING WITH BEARING

YDK402



OEM CODE: 150811-30639948-3M513K099AD
FORD: CMAX-FOCUS-KUGA

SHOCK ABSORBER BEARING

YDK500



OEM CODE: 1061722-7T163K155AA-98AG3K155AF
FORD: FOCUS-TOURNEO-TRANSIT

SHOCK ABSORBER MOUNTING

YDK502



OEM CODE: 1141459-DD3239060-3S616P082AA
FORD: BMAX-FIESTA-FUSION

GEARBOX MOUNTING

YDK503



OEM CODE: 1094591-9T166P082BA-98AB6P082AH
FORD: FOCUS-TOURNEO-TRANSIT

GEARBOX MOUNTING

YDK505



OEM CODE: 1061668-1231455-98AG5K743AF
FORD: CMAX-FOCUS

BALANCE ARM REAR

YDK200



OEM CODE: 8200103263-8200272424
NISSAN: PATROL-PRAIRIE-PRIMERA-SUNNY

ENGINE MOUNTING REAR

YDK202



OEM CODE: 8200053795-5433000QAA
NISSAN: KUBISTAR

SHOCK ABSORBER MOUNTING

YDK202-R



OEM CODE: 8200053795-5433000QAA
NISSAN: KUBISTAR

SHOCK ABSORBER MOUNTING WITH BEARING

YDK206



OEM CODE: 6001549205-8200575641-11360BV000
NISSAN: MICRA-NOTE-NV200-PRIMERA

ENGINE MOUNTING REAR

YDK207



OEM CODE: 543206968R-543207020R
NISSAN: QASHQAI-X TRAIL

SHOCK ABSORBER MOUNTING

YDK209



OEM CODE: 7700800107-8200651172-5432500QAA
NISSAN: KUBISTAR

SHOCK ABSORBER BEARING

YDK213



OEM CODE: 8200275524-8200742906-54467AX600
NISSAN: MICRA-NOTE-TIIDA

ENGINE CRADLE BUSH

YDK401



OEM CODE: 1230960-1305954-CV613K155B2B
MAZDA: 3

SHOCK ABSORBER MOUNTING

YDK402



OEM CODE: 150811-30639948-3M513K099AD
MAZDA: 3-5

SHOCK ABSORBER BEARING

YDK502



OEM CODE: 1141459-DD3239060-3S616P082AA
MAZDA: 2

GEARBOX MOUNTING

YDK505



OEM CODE: 1061668-1231455-98AG5K743AF
MAZDA: 3-5

BALANCE ARM REAR